

ASSEMBLING ADVICE

Assembling Clément Lunetier glasses is a straightforward process. There are several key points to follow for a perfect lens assembly:

1. Classic Beveled Glass Size: Ensure that the lens size matches the frame precisely, down to the tenth of a millimeter. Insert the lens from the rear side.
2. Inserting the Lens into the Frame: Insert the lens into the frame starting from the nasal (near the nose) side and then move to the temporal (towards the temples) side. We have beveled the frame on the temporal side to facilitate lens insertion. To ease the process further, you can use a manual grinder (very effective) to adjust the bevel of your lens.
3. If the Lens is Too Large (requires excessive force): Reduce the size if necessary (remember, wood fibers are not stretchable). Avoid forcing the lens.
4. Adjusting or Refitting Your Frame: The methods for readjusting or fitting your frame are the same as your usual practices. You can gently heat the frame to correct the face angle if needed.

CLEANING

Cleaning Instructions for Clément Lunetier Frames

Our Clément Lunetier frames are cleaned in the same way as acetate frames.

To revive the colors of the wood veneers, we provide you with a Maintenance Kit (refer to the instructions).

Please note: Do not use acetone or products like "essiclean" to clean the frames.